


GLOBAL*fiber* MiniCoder-1

- Støtter Windows
- Link til MiniCoder software:
https://www.globalfiber.no//userfiles/file/GF-MiniCoder%20v1_18%20installer.zip

Settings:









Program from database:

GF-MiniCoder

GLOBALfiber

Vendor name: Vendor PN:
Vendor SN: Date Code:
Bit Rate: 0.0 Gb/s Wavelength: 0 nm

Program from database

Select transceiver ▼
Select variation ▼
Select vendor ▼

Program

Ready...

- Velge Type transceiver/formfaktor, SFP/SFP+/SFP28/QSFP+/QSFP28/QSFP-DD.
- Velge hastighet: 1G/10G/25G/40G/100G/200G/400G.
- Versjon, SR/LR/ER/ZR/Tunable/Kobber/Bidi mm.

Velg type koding, CISCO, Extreme, Juniper mfl.

Velg bølgelengde, dB og type konnektor.

Skriver ny kode til transceiver, viser **Ready** nederst til høyre om alt er ok.

Diagnostics:

GF-MiniCoder

GLOBALfiber

Vendor name:

Vendor PN:

Vendor SN:

Date Code:

Bit Rate: 0.0 Gb/s

Wavelength: 0 nm

Program from database

Settings

Diagnostics

Temperature: 0.0 degC

Supply Voltage: 0.00 V

TxBiasCurrent: 0.0 mA

TxPower: 0.0 dBm

RxPower: 0.0 dBm

LaserTemperature: 0.0 degC

TECcurrent: 0.0 mA

Ready...

Viser enkel monitor funksjon (DDM) med optiske nivåer, temperatur, bølgelengde, Bit Rate, serienummer, Vendor name og Vendor vare nummer.